

**Test Equipment
Depot**



1-800-517-8431

99 Washington Street
Melrose, MA 02176
Phone 781-665-1400
Toll Free 1-800-517-8431

FLUKE®



Visit us at www.TestEquipmentDepot.com

1744/1743

Power Quality Logger

Users Manual

PN 2560353

April 2006 Rev.1, 6/06

© 2006 Fluke Corporation, All rights reserved. Printed in USA
All product names are trademarks of their respective companies.

Table of Contents

Title	Page
Introduction	1
Information and PC Software CD	1
Logger Power Supply	2
Power Interruptions.....	2
Introduction to the Logging Functions.....	2
Symbols	4
Safety Instructions	4
Qualified Personnel.....	6
Standard Equipment and Optional Accessories	6
Features.....	8
Power Network Configurations	10
Working with Logged Data.....	10
Using the Logger	11
Logging Jobs.....	11
Preparing the Logger for Use.....	12
Test Leads – Markings	14
Connecting Current Probes	14
Logging with Voltage Converters	15
Connecting the Logger.....	15
Connections in 3-Phase 4-Wire (Wye) Systems	18
Connections in 3-Phase 3-Wire (Delta) Systems	19
Connections for Single-Phase Logging.....	20
Connections for Medium-Voltage Networks	21
Phase-Phase Delta Logging	22
Phase-Ground, Wye-Logging	23
Logging with Two Voltage Converters and Two Current Transformers.....	24
Logging.....	25
Completing the Logging Job.....	26
Evaluating the Logged Data.....	27
Methods of Logging.....	27
Measuring Ranges.....	27
Signal Sampling.....	28
Resolution Accuracy.....	28
Voltage Variations	29

Min/Max Values.....	30
Voltage Interruptions.....	31
Voltage Dips and Swells	32
Voltage Harmonics.....	32
Current Harmonics.....	33
Mains Signaling.....	33
THDV – In Function A.....	34
Calculation of THD in Measuring Function P.....	35
Flicker	35
Unbalance.....	36
Frequency.....	36
Current Logging.....	37
Logging Function A	37
Crest Factor (CF).....	37
Power	37
Logger Parameters with Function P	38
Logger Parameters with Function A.....	41
Maintenance	45
Lithium Battery	45
Disposal.....	45
Technical Specifications.....	46
Logging Parameters – Overview	46
Maximum Number of Intervals for Logging Function P.....	47
General Information	47
Environmental Specifications.....	48
EMC.....	48
Power Supply	49
Measurement.....	49
Input Voltage.....	50
Current Input with Flexi Set.....	50
Current Input for Clamp	51
General Specifications.....	52
RMS Logging Slow Voltage Variations.....	52
Current Logging Values	52
Events Dips, Swells, Interruptions.....	52
Flicker	52
Power (Logging Functions A, P only) P, S, P	53
Harmonics	53
Statistics	53
Logging Function P	54
Logging Values	54
Application.....	54
Logging Function A – “All” parameters.....	55
Logging Values	55
Applications	56
PQ Log PC Application Software	57
Online Test.....	58
ASCII Export.....	59

Timeplot diagram.....	60
UNIPeDE DISDIP Table.....	61
Cumulative Frequency – Harmonics.....	62

Index

List of Tables

Table	Title	Page
1.	Symbols.....	4
2.	Standard Equipment.....	7
3.	Optional Accessories.....	7
4.	1744/1743 Power Quality Logger - Controls and Indicators	9
5.	Test Lead Markings.....	14
6.	Measuring Ranges.....	27
7.	Logging Parameters - Overview.....	46

List of Figures

Figure	Title	Page
1.	1743 and 1744 Power Quality Loggers	3
2.	1744/1743 Power Quality Logger - Front View	8
3.	Supplying Operating Power to the Logger	13
4.	Logging in a 3-Phase 4-Wire (Wye) System	18
5.	Logging in a 3-Phase 3-Wire (Delta) System	19
6.	Single Phase Logging	20
7.	Measuring 3-Phase Voltages in a 3-Wire (Delta) System with Three Voltage Converters	21
8.	PQ Log Settings for a 16 kV Network	22
9.	PQ Log Settings for a 16 kV Network	23
10.	Measuring 3-Phase Voltages in a 3-Wire System with Potential Transformers (Aron Measuring Circuit)	24
11.	PQ Log Settings for a 16 kV Network	25
12.	Selecting Voltage Input Ranges During Job Processing	28
13.	Measuring Voltage Variations	29
14.	Logging Min and Max Values	30
15.	Voltage Interruption	31
16.	Voltage Dips and Swells	32
17.	Measuring Flicker Values	36
18.	Online Test	58
19.	ASCII Export	59
20.	Timeplot Diagram	60
21.	UNIPEDE DISDIP Table	61
22.	Cumulative Frequency – For Voltage and Current Harmonics	62

1744/1743 Power Quality Logger

Introduction

The Fluke 1744 and 1743 Power Quality Loggers are sophisticated, robust, easy-to-use electrical power-recording devices for the electrician or power-quality specialist.

Note

This manual also refers to the 1744 or 1743 Power Quality Logger simply as “the Logger.”

You'll prepare the Logger for use with the included PQ Log software CD. You can then connect the Logger to an electrical power-distribution network to log a variety of power parameters, recorded as sequential averaged values over an averaging period you can define. The Logger can measure up to three voltages and four currents simultaneously.

The Logger enables you to conduct a load study over a specified period, or monitor power quality to discover and report disturbances in low- and medium-voltage networks.

The Logger has a light, compact design. Its case is sealed to IP 65 specifications, so it can be used outdoors in any weather.

Information and PC Software CD

The CD included with the Logger contains the PQ Log application software for Windows[®], along with users manuals in multiple languages, and the 1735 Upgrade Utility for installing firmware upgrades.

The PQ Log software prepares the Logger for use, and downloads data from the Logger to a connected PC. You can then view the logged data in graphical and tabular form, export it to a spreadsheet, or create reports for printing. For details and instructions, see the PQ Log Users Manual on the CD.

Logger Power Supply

The Logger does not include a power switch, but turns on automatically whenever its power supply leads are connected to a voltage in its allowed range. You can plug the Logger's power supply leads into a standard wall outlet (using the included adapter cord), or you can connect them directly to the power network under test (in parallel with the test leads) if there is no convenient wall outlet.

Power Interruptions

The Logger can sustain operation through power interruptions of up to three seconds, long enough for most common interruptions. In longer interruptions, the Logger shuts down, then resumes logging when power returns.

Introduction to the Logging Functions

The Logger monitors power quality and locates disturbances in low and medium voltage distribution networks. It measures up to three voltages and four currents. Logged values are saved in your choice of sequential averaging periods. You graphically or numerically evaluated measured values with PQ Log.

The Model 1744 has two types of logging functions: logging function A (Advanced) and logging function P (Power). Function A is the full set of parameters, and function P provides logging capability optimized for load studies and basic power logging. Function P contains every parameter in Function A except voltage and current harmonics and interharmonics. Model 1743 provides only logging function P.

Measured values are saved as averaged values over user-selected averaging periods. You can evaluate measured values graphically or in tabular form with PQ Log software.

Logging function parameters:

- RMS Voltage of each phase (average, min, max)
- RMS Current of each phase and neutral (average, min, max)
- Voltage events (dips, swells, interruptions)
- Power (kW, kVA, kVAR, Power PF, Power tangent)

Power Quality Logger

Introduction to the Logging Functions

- Energy, total energy
- Flicker (Pst, Plt)
- Voltage THD
- Current THD
- Current CF
- Voltage harmonics to the 50th (not in P function)
- Voltage interharmonics (not in P function)
- Mains signaling voltage
- Unbalance
- Frequency













Figure 1. Model 1744/1743 Power Quality Loggers

egb002.eps

Symbols

Table 1 lists the symbols used on the instrument and in this manual.

Table 1. Symbols

Symbol	Description
	Important information. See the manual.
	Hazardous voltage.
	Earth ground.
	Double insulation.
	Direct current (DC).
	Conforms to European Union requirements.
	Canadian Standards Association is the certified body used for testing compliance to safety standards.
	Do not dispose of this product as unsorted municipal waste. Contact Fluke or a qualified recycler for disposal.
	Conforms to relevant Australian Standards.

Safety Instructions

Please read this section carefully. It will make you familiar with the most important safety instructions for using the Logger.

Warnings identify conditions and actions that pose safety hazards to the user, and **Cautions** identify conditions and actions that can damage the Logger.

⚠ ⚠ Warnings

- **To avoid electrical shock, do not connect any part of the Logger to systems that have higher voltages to ground (earth) than are marked on the Logger.**
- **Areas between the power company meter and the source of the distribution system are characterized as CAT IV areas. To avoid electrical shock or equipment damage, never connect the Logger to power in CAT IV areas if the voltage-to-earth ground is greater than 300 V.**
- **To avoid damaging the Logger, never connect its voltage measuring inputs to phase-to-phase voltages higher than 830 V.**
- **To avoid damaging the Logger, never connect the power supply leads to voltages higher than 660 V RMS ac.**
- **The Logger is to be used and handled only by qualified personnel (see page 6).**
- **Maintenance work on the Logger must be done only by qualified service personnel.**
- **Use only the current probes specified in this manual. If you use flexible current probes, wear suitable protective gloves or work on de-energized conductors.**
- **Do not expose the Logger to moisture or humidity.**
- **To prevent electrical shock, always connect power supply and voltage test leads to the Logger before connecting to the load.**
- **All accessories must be approved for 600 V CAT III or higher.**
- **Use the Logger only with its original standard equipment or with approved optional accessories, as listed in Table 2 and Table 3 in this manual.**

- **Connect clip-on current transformers and/or Flexi Set to insulated live conductors only.**
- **If measuring sensors are to be connected to non-insulated live conductors, additional personal protective measures must be taken as required by local government agencies.**

⚠ Caution

To avoid damage, use the 1744/1743 Power Quality Logger, only with the following nominal voltages:

- **Single-/3-phase, 4-wire (Wye) systems (P-N): 69 V to 480 V**
- **3-phase 3-wire(Delta) systems (P-P): 120 V to 830 V**

⚠⚠ Warning

To avoid electrical shock, or damaging the Logger's internal protective circuitry or weatherproof seal, do not open the Logger.

Qualified Personnel

The following qualifications are required for using the Logger safely:

- Trained and authorized to switch on/off, ground (earth), and mark power distribution circuits and devices in accordance with electrical engineering safety standards.
- Trained or instructed in safety engineering standards for maintaining and using appropriate safety equipment.
- Trained in first aid.

Standard Equipment and Optional Accessories

Table 2 lists the standard equipment for the 1744/1743 Power Quality Logger, and Table 3 lists optional accessories.

Table 2. Standard Equipment

Equipment	Model/Part Number
Power Quality Logger	1744/1743
International IEC Power Plug Adapter Set	2441372
RS232 Cable, Red, Null-Modem	2625531
Shielded 4-Phase Flexi Set (15 A/150 A/1500 A/3000 A)	FS17XX
Dolphin Clip, Black (4x)	2540726
Color Coding Wire Clips	WC17XX
Soft Case	1642656
English Users Manual	2560353
CD with Users Manual (English, German, French, Spanish, Portuguese, Simplified Chinese, Italian), and PQ Log software (same languages as the manual)	2583487
Power Cord	2561702
USB Adapter	

Note

Power supply and voltage measuring leads are built into the 1744/1743 Power Quality Logger.


Table 3. Optional Accessories

Description	Accessory
3-Phase Flexi Set	MBX 3FLEX
3-Phase 1 A/10 A micro CT	EPO405A
Pole Mounting Kit	1743/4 Pole Kit
Permlink Software for Modem	Permlink
Magnetic Hanging Kit	1281997

Inspect the contents of the shipping box for completeness and damage. Report any damage to the shipper.

Features

This section introduces the Logger's controls, indicators, and other features. Refer to Figure 2 and Table 4.



egb021.eps

Figure 2. 1744/1743 Power Quality Logger - Front View

Table 4. 1744/1743 Power Quality Logger - Controls and Indicators

Item	Name	Description
①	Power supply leads and 3-phase plus neutral voltage test leads	<p>Power supply voltage range: 88-660 V ac or 100-350 VDC, 50 Hz / 60 Hz, 600 V CAT III.</p> <p>Fixed installed voltage input cables for L1 or A, L2 or B, L3 or C, N.</p> <p>The highest permissible nominal voltage for power supply input is 660 V.</p> <p>The highest permissible nominal voltage for signal input is 830 V in a 3-wire network with Delta connection.</p> <p>In a 4-wire network with Wye connection, the highest permissible nominal voltage is 480 V.</p> <p>When using PTs and CTs for measuring voltage and current in a medium-voltage network, refer to the IEC 60044 international standard for guidelines.</p>
②	RS232 interface port	The serial RS232 interface is used to communicate with a PC. The Logger is connected to the PC's serial port (or a modem for remote communication) using the interface cable. Use a USB adapter if necessary.
③	START/STOP	The START/STOP button is used to start or end switch-operated logging sessions.
④	Channel LEDs	<p>The logging channel LEDs indicate whether the applied voltages and currents are within the nominal range set using the PQ Log software.</p> <p>Continuously on = Logging signal in nominal range</p> <p>Short blinks = No or low-level signal</p> <p>Long blinks = Overload</p>
⑤	Power status LED	<p>Continuously on = Power supply voltage in permissible range</p> <p>Off = No power</p>
⑥	Connector for Flexi Set or current clamps	<p>Flexi sets or current clamps are detected automatically at power-up. If you change the current probe type, be sure to remove and restore power so the Logger will detect the new current probe.</p> <p>Nominal ranges for the Flexi Set are 15 A, 150 A, 1500 A, and 3000 A ac. Nominal input for current clamps is 0.5 V.</p>
⑦	Logging status LED	<p>Continuously on = Logging in progress</p> <p>Blinking = Logging stopped or not started</p>

Power Network Configurations

You can set up the Logger to work with several power network configurations:

- Single-phase voltage
- Single-phase voltage, current, power
- 3-phase voltage
- 3-phase voltage, 3-phase current, power
- 3-phase voltage, 3-phase current, neutral current, power

Note

3-phase logging with no neutral current can be done with appropriate optional accessories (available separately).

Working with Logged Data

Logged data can be evaluated using the PQ Log software to provide the following:

- Amount, date/time, and duration of quick and slow voltage variations
- Half-cycle 10 ms-extreme values for 50 Hz (8.3 ms at 60 Hz) MIN and MAX for each measuring interval
- Depth and duration of voltage dips
- Correlation between peak current and voltage dips
- 95%-flicker values according to EN 50160
- Number and duration of interruptions
- Compliance of harmonic levels with defined limits
- Mean and peak values of phase currents
- Value of neutral conductor current
- Current total harmonic distortion (THD) of phase and neutral conductor currents
- Profile of active, reactive, and apparent power versus time
- Monitoring of power factor (PF), and information about effectiveness of compensation systems
- Graphical representations of logging data and statistics

Using the Logger

This section explains how to operate the 1744/1743 Power Quality Logger.

A typical logging session includes four steps:

1. Preparing the Logger for use with the PQ Log software.
2. Installing the Logger at the logging site.
3. Leaving the Logger to collect data for a period.
4. Downloading and evaluating the logged data.

These steps are described in the following pages.

Logging Jobs

Logging jobs are defined using the PQ Log software, and transferred to the Logger over the RS232 cable. Each job contains the following information:

- Logging function (P for Model 1743, and P or A for Model 1744)
- Measuring period, defined by start and end times
- Time activated, switch or immediate job
- Input range
- Nominal voltage, primary and secondary voltage for logging with voltage converters
- Logging of phase-neutral wire or phase-phase
- Memory model
- Averaging period length
- Logging time periods
- Interharmonics and signaling voltages
- Limit values for events
- Memory model for events: circular (first-in/first-out, continuous), or linear (quit logging when logging period is finished)
- Logging of current-neutral wire
- Converter ratios for current and voltage if using potential transformers (PTs) and current transformers (CTs) at a medium-voltage network site


Preparing the Logger for Use

Prepare the 1744/1743 Logger for use with the PQ Log software as follows (see Figure 3):

1. Connect the Logger to line power. Use the power supply cables to connect to an outlet, or to the test leads phase and neutral for Wye configurations, or any two-phase leads for delta.

⚠ Caution

If you are powering the Logger in parallel with the test leads, and the voltage under test at the Logger power supply connections could be greater than 660 V RMS ac, plug the power supply leads into an outlet instead. Otherwise, you could damage the Logger.



egb031.eps

Figure 3. Supplying Operating Power to the Logger

2. Connect the RS232 interface cable to the serial port of your PC.

3. Run the PQ Log software as described in the PQ Log Users Manual.
4. Set up the Logging job and transfer the settings to the Logger.

Test Leads – Markings

The 1744/1743 Logger includes built-in, labeled test leads for voltage terminals L1 or A, L2 or B, L3 or C, and N, as well as two for the internal power supply. The Flexi Set or current clamp sets are connected by a seven-pin plug to the Logger. Color coding clips are provided for your convenience.

Table 5. Test Lead Markings

Test Leads	Markings
Phase L1 or A	L1 / A
Phase L2 or B	L2 / B
Phase L3 or C	L3 / C
Neutral wire N	N
Supply	“Supply”
Supply	“Supply”

Connecting Current Probes

Connect current clamps and Flexi Set probes so that current will flow in the direction marked by arrows on the probes. Current must flow from the energy generator to the energy consumer (the load) in order to maintain a positive active power. (The polarization of the test lead for neutral conductor current is not significant, because the phase angle of the neutral conductor current is not evaluated.)

Note

Make sure the clip-on probes are connected to the appropriate phase: V_{L1} with I_{L1} for a P-N measurement or V_{L12} with I_{L1} for a P-P measurement.

Logging with Voltage Converters

The 1744/1743 Logger includes an adjustable converter ratio that enables it to be used with voltage converters (potential transformers, or PTs).

Note

When logging with voltage converters, make sure the power supply cables are not connected in parallel to the voltage test leads, or the Logger's power consumption can reduce accuracy.

The converter ratio is defined using the PQ Log software.

Connecting the Logger

⚠ ⚠ Warnings

- **To avoid electrical shock, do not connect any part of the Logger to systems that have higher voltages to ground (earth) than are marked on the Logger.**
- **Areas between the power company meter and the source of the distribution system are characterized as CAT IV areas. To avoid electrical shock or equipment damage, never connect the Logger to power in CAT IV areas if the voltage-to-earth ground is greater than 300 V.**
- **To avoid damaging the Logger, never connect its voltage measuring inputs to phase-to-phase voltages higher than 830 V.**
- **To avoid damaging the Logger, never connect the power supply leads to voltages higher than 660 V RMS ac.**
- **The Logger is to be used and handled only by qualified personnel (see page 6).**
- **Maintenance work on the Logger must be done only by qualified service personnel.**

- **Use only the current probes specified in this manual. If you use flexible current probes, wear suitable protective gloves or work on de-energized conductors.**
- **Do not expose the Logger to moisture or humidity.**
- **To prevent electrical shock, always connect power supply and voltage test leads to the Logger before connecting to the load.**
- **All accessories must be approved for 600 V CAT III or higher.**
- **Use the Logger only with its original standard equipment or with approved optional accessories, as listed in Table 2 and Table 3 in this manual.**
- **Connect clip-on current transformers and/or Flexi Set to insulated live conductors only.**
- **If measuring sensors are to be connected to non-insulated live conductors, additional personal protective measures must be taken as required by local government agencies.**

⚠ Caution

To avoid damage, use the 1744/1743 Power Quality Logger, only with the following nominal voltages:

- **Single-/3-phase, 4-wire (Wye) systems (P-N): 69 V to 480 V**
- **3-phase 3-wire (Delta) systems (P-P): 120 V to 830 V**

⚠⚠ Warning

To avoid electrical shock, or damaging the Logger's internal protective circuitry or weatherproof seal, do not open the Logger.

Connect the Logger as follows:

Note

Δ (Delta) or Y (Wye) measurements

The 1744/1743 Logger is prepared for logging in 3-phase 4-wire (Wye) systems (P-N), or 3-phase 3-wire (Delta) systems (P-P). Please note the different types of connection and configuration in the PQ Log software.

1. Connect all required measuring leads.
2. If you want to supply the Logger from an extra outlet, use the supplied line power adapter. The power supply leads can also be connected in parallel to the voltage test leads, but the voltage is limited to 660 V RMS ac.
3. Connect the current clamp set or Flexi Set to the Logger.
4. Connect the current sensor to the conductor under test.
5. Connect the dolphin clips to the test leads. For 3-phase, 4-wire systems, connect the N-test lead first, and then the other phases.

Connections in 3-Phase 4-Wire (Wye) Systems

The following figure shows the connections for logging 3-phase 4-wire (Wye) systems:





Figure 4. Logging in a 3-Phase 4-Wire (Wye) System

egb003.eps

Connections in 3-Phase 3-Wire (Delta) Systems

Figure 5 shows the connections for logging 3-phase 3-wire (Delta) systems.



egb004.eps

Figure 5. Logging in a 3-Phase 3-Wire (Delta) System

The test lead N can be left open, or connected to ground potential.

Connections for Single-Phase Logging

Figure 6 shows the connections for logging single-phase systems.





Figure 6. Single-Phase Logging

egb005.eps

Connections for Medium-Voltage Networks

In a 3-phase 3-wire (Delta) system with three separate voltage converters and three current transformers, the Logger can measure phase-phase (P-P, Delta) or phase-N (P-N, Wye). See Figure 7.



egb006.eps

Figure 7. Measuring 3-Phase Voltages in a 3-Wire (Delta) System with Three Voltage Converters

Phase-Phase Delta Logging

Figure 7 shows the connections for phase-phase Delta logging.

1. Connect the voltage test leads to the outputs of the voltage transformers (VTs).
2. In PQ Log, select the measuring range with the matching nominal voltage and P-P logging.
3. Enter the correct converter/transformer ratio for current and voltage.

Voltage

Min-Max-value: 0.5 periods Voltage transformer

Nominal voltage: 16000 V Primary voltage: 16000 V

Input range: 120 V, P-P Secondary voltage: 100 V

Phase L1, L2 and L3

Additional current transformer

Nominal current: 1000 A Primary current: 1000 A

Current transformer: 5 A/0.5 V Secondary current: 5 A


Special current transformer

egb007.bmp

Figure 8. PQ Log Settings for a 16 kV Network

Phase-Ground, Wye-Logging

Figure 7 shows the Phase-Ground, Wye-Logging. Figure 9 shows typical PQ Log settings for using potential transformers (PTs) and current transformers (CTs) with a 16 kV network.



Voltage

Min-Max-value: 0.5 periods Voltage transformer

Nominal voltage: 9237 V Primary voltage: 9237 V

Input range: 69 V, P-N Secondary voltage: 57.74 V

Phase L1,L2 and L3

Additional current transformer

Nominal current: 1000 A Primary current: 1000 A

Current transformer: 5 A/0.5 V Secondary current: 5 A

Special current transformer

egb010.bmp

Figure 9. PQ Log Settings for a 16 kV Network


1. Connect the voltage test leads to the outputs of the voltage transformers (VTs).
2. In PQ Log, select the measuring range with P-N logging and matching nominal voltage.
3. Enter the correct converter/transformer ratio for current and voltage.

Note

Current clamp sets are available for 1 A current transformers.

Logging with Two Voltage Converters and Two Current Transformers

In 3-phase 3-wire systems with two voltage converters (VTs) and two current transformers (CTs) in an Aron or Blondel measuring circuit, the Logger can measure only phase-phase (P-P, Delta).



egb009.eps

Figure 10. Measuring 3-Phase Voltages in a 3-Wire System with Potential Transformers (Aron Measuring Circuit)

1. Connect the voltage test leads L2 or B and N to the common ground point.
2. In PQ Log, select the measuring range with P-P logging and matching nominal voltage.
3. Enter the correct converter/transformer ratio for current and voltage.

The image shows two screenshots of the PQ Log settings interface. The top screenshot is titled 'Voltage' and contains the following settings: 'Min-Max-value' is set to '0.5 periods' (dropdown), 'Voltage transformer' is checked, 'Nominal voltage' is '16000' V, 'Primary voltage' is '16000' V, 'Input range' is '120 V, P-P' (dropdown), and 'Secondary voltage' is '100' V. The bottom screenshot is titled 'Phase L1,L2 and L3' and contains: 'Additional current transformer' is checked, 'Nominal current' is '1000' A, 'Primary current' is '1000' A, 'Current transformer' is '5' A/0.5 V (dropdown), 'Secondary current' is '5' A, and 'Special current transformer' is unchecked.

egb007.bmp

Figure 11. PQ Log Settings for a 16 kV Network

Note

Current clamp sets are available for 1 A current transformer.

Logging

When the Logger is connected and ready, you can perform three types of logging:


- **Switch-activated job:** The status LED is blinking. Press the START/STOP button once. As soon as the job is active, the LED is on continuously. If needed, the job can be cancelled after running for at least one minute, and restarted later.

- **Time-activated job:** The Logger starts logging as soon as the preprogrammed start time is reached, and stops at the defined end time.
- **Immediate job:** The Logger starts logging as soon as power is on.

Note the following about logging jobs:

- The connection can be verified using the logging channel LEDs. If all three LEDs are lit continuously, the connection and the signal levels are within nominal range. For details, see Table 4 in the Features section.
- The unit/job status is indicated by the status LED. For details, see Table 4 in the Features section.

Completing the Logging Job

1. Terminate the job as follows:
 - **For switch-activated jobs:** At the end of the logging period, stop the logging job by pressing the START/STOP button.
 - **For time-activated and immediate jobs:** Stop the job in PQ Log with the  icon, or with menu Logger/Stop logging.

Note

Make sure the logging job is stopped with the START/STOP button (switch-activated jobs) or PQ Log (time-activated jobs) before the test leads or power supply leads are removed. Otherwise, the Logger will record a voltage interruption.

Only switch-activated jobs can be aborted. Time-activated jobs are terminated only when the programmed measuring time has elapsed.

2. Remove the test leads of the three phases. Be sure to remove the measuring cable of the neutral wire *last*.
3. Remove the current probes.

Evaluating the Logged Data

You'll use PQ Log to evaluate the logged data. Data can be read out during logging as well as at the end.

1. Connect the Logger to line power.
2. Connect the RS232 interface cable to your PC's serial port, then to the Logger.
3. Start the PQ Log software.
4. Use PQ Log to transfer the data from the Logger to the PC.
5. Once the data is transferred, remove the RS232 interface cable and operating power from the Logger.
6. Evaluate the data using PQ Log.

For details, refer to the PQ Log manual.

Methods of Logging


The following section describes methods of logging using the 1744/1743 Logger.

Measuring Ranges

The Logger has three input ranges for each of its two connection systems: Wye connection (3-phase, 4-wire) and Delta connection (3-phase, 3-wire).

Table 6. Measuring Ranges

Connection	Nominal Voltages (Wye/Delta) Max. Input Voltage			
Wye/Delta	69 V / 120 V	115 V / 200 V	230 V / 400 V	480 V / 830 V
Phase/Neutral 3-phase 4 wire	69 V ~, +20%	115 V ~, +20%	230 V ~, +20%	480 V ~, +20%
Phase/Phase 3-phase 3 wire	120 V ~, +20%	200 V ~, +20%	400 V ~, +20%	830 V ~, +20%



egb015.bmp

Figure 12. Selecting Voltage Input Ranges During Job Processing

Note

For P-P logging, the P-P voltage must be entered as the nominal voltage (e.g. 400 V for 230 V systems).

Signal Sampling

Input signals (up to three voltages and four currents) are filtered with an anti-aliasing filter, and digitized with a 16-bit A/D converter. The sampling rate is 10.24 kHz. All parameters are calculated from this data.

Resolution Accuracy

Resolution and accuracy depend on the logging parameter. For details, see

Technical Specifications” on page 46.

Voltage Variations

The interval value of the voltage is defined as the mean value of the RMS values over the interval length defined in PQ Log.

Averaging intervals can be set in PQ Log to the following:

- 1, 3, 5, 10, or 30 seconds
- 1, 5, 10, 15, or 60 minutes




Figure 13. Measuring Voltage Variations

egb016.eps

Note

For logging in Wye configuration using logging function A, the phase-phase voltages are measured and displayed separately from the logging of the phase-neutral voltages.

Min/Max Values

Logging detects the highest and lowest voltage RMS values and the highest current RMS value during the test interval, using a minimum resolution of 10 ms.

The response time can be set in PQ Log to the following:

- 0.5 or 1 line power period
- 200 ms
- 1, 3, or 5 seconds.




Figure 14. Logging Min and Max Values

egb017.jpg

Voltage Interruptions

The Logger records two types of interruptions:

- All measured RMS values of input voltages that are $< 1\%$ of the nominal voltage. (This threshold can be adjusted in PQ Log.)
- Interruptions > 10 ms (0.5 line power periods).

The start time and duration of each interruption are registered.




Figure 15. Voltage Interruption

egb018.eps

Voltage Dips and Swells

If the voltage passes the upper limit ($V_N + 10\%$) or lower limit ($V_N - 10\%$), the event is registered as a voltage swell or dip, respectively (thresholds are adjustable in PQ Log).

The duration, time, and extreme value of the dip or swell is also recorded.




Figure 16. Voltage Dips and Swells

egb019.eps

Voltage Harmonics

Voltage harmonics are defined as voltage components that have a frequency that is an integer multiple of the fundamental frequency of the line power voltage. Logging function A records each individual voltage harmonic, up to the 50th order. These values are averaged over the interval length defined in PQ Log.

Current Harmonics

Current harmonics are defined as current components that have a frequency that is an integer multiple of the fundamental frequency of the line power current. Logging function A records each individual harmonic of the phase currents and the neutral current, up to the 50th order, and presents the harmonics as absolute values. The values are averaged over the interval length defined in PQ Log.

Mains Signaling

Voltage components that have frequencies that are not integer multiples of the fundamental frequency of the line power voltage are called Mains Signaling voltages or ripple-control voltages (“interharmonics”).

The Logger can be programmed to record up to five interharmonics, with a resolution of 5 Hz. This function can also be used to monitor ripple-control signals, by entering the signal frequency of the local utility.

The Logger measures the three-second RMS value of each interharmonic, and establishes statistics for EN 50160 evaluation. These statistics are available after a minimum recording time of 24 hours, or after regular termination of the measuring job, and can be exported from PQ Log and evaluated later.

Additionally, the Logger provides a long-term recording of the interharmonics. You can select from the following special measurement methods in the PQ Log software:

- 200 ms maximum value (recommended for estimating ripple-control signal levels)
- 200 ms minimum value
- 3 seconds maximum value
- Average value over interval

In PQ Log, the frequency can be entered with a resolution of 0.5 Hz, but for evaluation the values are corrected to a bandwidth of 5 Hz. One frequency can be defined for each band: for example, for a ripple-control signal of 183 Hz, the values will be corrected to 185 Hz. Interharmonics of voltages and currents with these frequencies are recorded.

See the PQ Log manual for details.

THDV – In Function A

$$\text{Function A: } THDV = \frac{\sqrt{\sum_{n=2}^{50} V_n^2}}{V_1}$$

V_n : RMS value of harmonic frequency #n.

V_1 : RMS value of the fundamental frequency.

THDV: total contents of harmonics of the line power voltage as a percentage of the fundamental.

This algorithm is according to EN 61000-4-7.

THD of currents:

$$\text{Function A: } THDI = \frac{\sqrt{\sum_{n=2}^{50} I_n^2}}{I_1} \quad \text{and} \quad THDI(A) = \sqrt{\sum_{n=2}^{50} I_n^2}$$

I_n : RMS value of harmonic frequency #n.

I_1 : RMS value of the fundamental frequency.

THDI: total contents of harmonics of the current as a percentage of the fundamental.

Calculation of THD in Measuring Function P

THD – Measuring Function P

Function P does not measure harmonic values.

$$\text{Voltages: } THDV = \frac{\sqrt{V_{RMS}^2 - V_1^2}}{V_1}$$

V_{RMS} : RMS value of total signal

V_1 : RMS value of the fundamental

$$\text{Currents: } THDI = \frac{\sqrt{I_{RMS}^2 - I_1^2}}{I_1}$$

I_{RMS} : RMS value of the total signal.

I_1 : RMS value of the fundamental.

Note

THDI for currents < 5% of IE (measuring range) can have additional uncertainties, or can be suppressed.

Harmonics up to 50th order are taken into account.

Flicker

Flicker is the visual impression of unsteadiness in a light source whose luminance or spectral distribution changes over time. Flicker is logged in accordance with the IEC 61000-4-15 standard. The short-term (st) flicker Pst_t is logged over a default standard interval of 10 minutes, and is used to calculate the long-term (lt) flicker Plt (by taking the sliding average of 12 short-term values). The interval value can be changed as needed in PQ Log.

Formula for Plt Function

$$Plt = \sqrt[3]{\sum_{i=1}^{12} \frac{Pst^3}{12}}$$




Figure 17. Measuring Flicker Values

egb020.eps

Unbalance

The ratio of negative-to-positive sequence harmonics is calculated, with the angles and magnitudes of the phase voltages taken into account. These values are averaged over the interval length defined in PQ Log.

Frequency

The line power frequency is measured and averaged over 10 seconds, and the resulting values are divided into 42 classes for establishing statistics. Values are also averaged over the interval length defined in PQ Log.

Current Logging

The maximum values of the currents (L1 or A, L2 or B, L3 or C, and N) are measured, and the interval value of the current is calculated using the mean value over the RMS values of the interval defined in PQ Log.

Logging Function A

If a 3-phase current sensor is connected, the neutral current is calculated on a sample basis from the phase currents. If a 3-phase+N sensor is detected, you can select between logging and calculating the neutral current in PQ Log.

I_{peak}

The peak values of the current (samples, not RMS values) are averaged in the PQ Log software over the predefined measuring interval.

Note

Short peak values do not contribute much to the average value, and so I_{max} can be higher than I_{peak} .

Crest Factor (CF)

The crest factor (CF) of the currents (L1 or A, L2 or B, L3 or C, and N) is the ratio of current peak value divided by current RMS value, and is averaged over the interval length defined in PQ Log. For sinusoidal signals: CF = 1.41, and for square waves: CF = 1.00

Power

The power values (L1 or A, L2 or B, L3 or C and N) are averaged over the interval length, and the maximum value of each is recorded.

The response time can be set to 1 second or 1 minute, and is independent of the response time for voltage and current.

In logging function P, the active power, apparent power, and reactive power of the phases and total power of all three phases is calculated.

Logging function A also calculates the distorting power D of the phases, and D_{total} .

Logger Parameters with Function P

The following are the parameters of the 1744/1743 Logger with function P.

RMS value of voltage and current.
Basic values on 200 ms per phase.

$$V_{bas} = \sqrt{\frac{1}{N} \cdot \sum_{i=1}^N V_i^2}$$

$$I_{bas} = \sqrt{\frac{1}{N} \cdot \sum_{i=1}^N I_i^2}$$

N: Number of samples in 200 ms intervals
(2048)

RMS value of voltage and current
per logging interval per phase

$$V_{RMS} = \frac{1}{M} \cdot \sum_{j=1}^M V_{bas\ j}$$

$$I_{RMS} = \frac{1}{M} \cdot \sum_{j=1}^M I_{bas\ j}$$

M: Number of 200 ms intervals per
logging interval

Active power based on samples.
Basic value on 200 ms per phase.

$$P_{bas} = \frac{1}{N} \sum_{i=1}^N V_i \cdot I_i$$

Active power per logging interval
per phase

$$P = \frac{1}{M} \cdot \sum_{j=1}^M P_{bas\ j}$$

P_{bas} : 200 ms value

M: Number of 200 ms intervals per
logging interval

Total active power on all three
phases

$$P_{total} = \sum_{k=1}^3 P_k$$

Power Quality Logger Logger Parameters with Function P

P_k : Active power of the phase

k: Phase (k = 1, 2, 3)

Absolute value of the active power per interval per phase. Parameter in PQ Log: |P|.

$$P_{betr} = \frac{1}{M} \cdot \sum_{j=1}^M |P_{bas\ j}|$$

M: Number of 200 ms intervals per logging interval

Sum of the absolute value of the total active power on all three phases. PQ Log parameter: |P|_{total}.

$$P_{betr\ total} = \sum_{k=1}^3 (P_{betr\ k})$$

K: Phase (k = 1, 2, 3)

Apparent power per phase

$$S_{bas} = \sqrt{P_{bas}^2 + Q_{bas}^2}$$

Apparent power per logging interval per phase

$$S = \frac{1}{M} \cdot \sum_{j=1}^M S_{bas\ j}$$

Total apparent power on all three phases

$$S_{total} = \sum_{k=1}^3 S_k$$

Power factor per phase

$$PF = \lambda = \frac{Q}{|Q|} \cdot \frac{|P|}{S}$$

Total power factor on all three phases

$$PF_{total} = \lambda_{total} = \frac{|P_{total}|}{S_{total}} \cdot \frac{Q_{total}}{|Q_{total}|}$$

Tangent φ per phase

$$\tan \varphi = \frac{Q}{P}$$

Tangent φ total on all three phases

$$\tan \varphi_{total} = \frac{Q_{total}}{P_{total}}$$

Active energy per phase and total

Active power accumulated on each logging interval

Note

The sign of the active power P gives the direction of the power flow (positive: from generator to load), and the sign of the power factor distinguishes between inductive load (positive) and capacitive load (negative).

Sign of PF, $\tan \varphi$, $\cos \varphi$:

- Sign “+” : Q positive (“inductive”)
- Sign “-” : Q negative (“capacitive”) independent of the sign of active power P

Logger Parameters with Function A

The following are the parameters of the 1744/1743 Logger with function A.

TRMS value of voltage and current. Basic values on 200 ms per phase.

$$V_{bas} = \sqrt{\frac{1}{N} \cdot \sum_{i=1}^N V_i^2}$$

$$I_{bas} = \sqrt{\frac{1}{N} \cdot \sum_{i=1}^N I_i^2}$$

N: Number of samples in 200 ms intervals (2048)

RMS value of voltage and current per logging interval per phase

$$V_{RMS} = \sqrt{\frac{1}{M} \cdot \sum_{j=1}^M V_{basj}^2}$$

$$I_{RMS} = \sqrt{\frac{1}{M} \cdot \sum_{j=1}^M I_{basj}^2}$$

M: Number of 200 ms intervals per logging interval

Active power calculated from FFT from samples of voltage and current. Basic value on 200 ms per phase.

$$P_n = V_n \cdot I_n \cdot \cos \varphi_n$$

V_n : RMS value of voltage harmonics of order n

I_n : RMS value of current harmonics of order n

n: Order of the harmonics

φ_n : Phase angle between current and voltage harmonics of order n

P_n : Harmonics of the active power of order n

Fundamental

$$P_{bas} = \sum_{n=1}^{50} P_n$$

$$Phl_{bas} = P_1$$

Active power of logging interval per phase

$$P = \frac{1}{M} \cdot \sum_{j=1}^M P_{bas\ j}$$

$P_{bas\ j}$: to 200 ms value

M: Number of 200 ms intervals per logging interval

Total active power on all three phases

$$P_{total} = \sum_{k=1}^3 P_k$$

P_k : Active power of the phase

k: Phase (k = 1, 2, 3)

Absolute value of the active power per interval per phase

$$P_{betr} = \frac{1}{M} \cdot \sum_{j=1}^M |P_{bas\ j}|$$

Sum of the absolute values of the active power on all three phases

$$P_{betr\ total} = \frac{1}{M} \sum_{j=1}^M |P_{bas\ 1} + P_{bas\ 2} + P_{bas\ 3}|$$

Apparent power based on RMS values of voltage and current. Basic values on 200 ms per phase

$$S_{bas} = V_{bas} \cdot I_{bas}$$

Apparent power per logging interval per phase

$$S = \frac{1}{M} \cdot \sum_{j=1}^M S_{bas\ j}$$

$S_{bas\ j}$: 200 ms value

M: Number of 200 ms intervals per logging interval

Total apparent power on three phases

$$S_{total} = \sum_{K=1}^3 S_k$$

k: Phase (k = 1, 2, 3)

Distortion power. Basic value on 200 ms per phase

$$D_{bas} = \sqrt{S_{bas}^2 - P_{bas}^2 - Q_{bas}^2}$$

Distortion power per interval per phase

$$D = \frac{1}{M} \cdot \sum_{j=1}^M D_{bas j}$$

$D_{bas j}$: 200 ms value

M: Number of 200 ms intervals per logging interval

Total distortion power on three phases

$$D_{total} = \sum_{k=1}^3 D_k$$

Distortion power per phase

$$PF = \lambda = \frac{|P|}{S} \cdot \frac{Q}{|Q|}$$

Total distortion power on three phases

$$PF_{total} = \lambda_{total} = \frac{|P_{total}|}{S_{total}} \cdot \frac{Q_{total}}{|Q_{total}|}$$

Tangent φ per phase

$$\tan \varphi = \frac{Q}{P}$$

Total tangent φ on three phases

$$\tan \varphi_{total} = \frac{Q_{total}}{P_{total}}$$

Active power of the fundamental per phase
Basic value for 200 ms.

$$Ph1_{bas} = P_1$$

Active power of the fundamental per phase per interval

$$Ph1_{bas} = \frac{1}{M} \cdot \sum_{j=1}^M Ph1_{bas j}$$

Total active power of the fundamental for three phases

$$Ph1_{total} = \sum_{k=1}^3 Ph1_k$$

Apparent power of the fundamental per phase.
Basic value for 200 ms.

$$Sh1_{bas} = V_1 \cdot I_1$$

Apparent power of the fundamental per phase per interval

$$Sh1 = \frac{1}{M} \cdot \sum_{j=1}^M Sh1_{bas\ j}$$

Power factor of the fundamental per phase

$$\cos \varphi_1 = \frac{|Ph1_{total}|}{Sh1} \cdot \frac{Qh1}{|Qh1|}$$

Total power factor on all three phases

$$\cos \varphi_{total} = \frac{|Ph1_{total}|}{Sh1_1 + Sh1_2 + Sh1_3} \cdot \frac{Qh1_{total}}{|Qh1_{total}|}$$

Active energy per phase and total

Active power accumulated on each logging interval

Sign of PF, tan φ , cos φ :

- Sign “+” : Q positive (“inductive”)
- Sign “-” : Q negative (“capacitive”) independent of the sign of active power P

Maintenance

⚠ Caution

Maintenance work on the Logger can be done only by trained and qualified personnel at a company-approved service center within the warranty period. For locations of Fluke Service Centers worldwide and contact information, see the Fluke website: www.fluke.com.

With proper use, the Logger does not require special maintenance other than periodic calibration at a Fluke calibration center.

If the Logger gets dirty, wipe it off carefully with a damp cloth without cleaning agents.

Lithium Battery

The 1744/1743 Logger contains a vanadium pentoxide lithium rechargeable battery. This battery is automatically recharged during normal operation.

Disposal

If you discard the Logger, you must recycle it at an appropriate recycling center as required by local regulations.

Technical Specifications

Logging Parameters – Overview

The following table gives an overview of the logging parameters.

Table 7. Logging Parameters – Overview

Measuring Function	P	A
Voltage: mean, min, max values	●	●
Current: mean, max values	●	●
Neutral current N	●	●
Voltage events	●	●
Power: P, P , S, D, PF, tangent	●	●
Power total P, P , S, D, PF, tangent	●	●
Energy	●	●
Flicker: Pst, Plt	●	●
Voltage harmonics		●
Current harmonics (L1 or A, L2 or B, L3 or C, N, up to 50 th order)		●
Interharmonics, ripple-control signals		●
THDV (voltage)	●	●
THDI (current)	●	●
CF (crest factor current)		●
Unbalance		●
Frequency		●

Maximum Number of Intervals for Logging Function P

The maximum recording period can be calculated by multiplying the interval time defined in PQ Log with the maximum number of intervals in the following table.

Version	P, V+I	A, V+I
Averaged periods	> 24,000	> 10,000

General Information

Intrinsic uncertainty	Valid for reference conditions, and guaranteed for two years.
Quality system	Developed, designed, and manufactured according to DIN ISO 9001.
Recalibration interval	Fluke recommends a recalibration interval of no more than two years, depending on use.
Reference conditions	23 C \pm 2 K, 230 V \pm 10% 50 Hz \pm 0.1 Hz / 60 Hz \pm 0.1 Hz Phase sequence: L1 or A, L2 or B, L3 or C Interval length: 10 minutes, 3-phase Wye configuration. Power supply: 88 to 265 V ac

Environmental Specifications

Working temperature range	-10 °C to +55 °C
Operating temperature range	0 °C to +35 °C
Storage temperature range	-20 °C to +60 °C
Reference temperature range	23 °C ± 2 K
Relative humidity	10 to 90%, no condensation
Housing	Robust, compact housing of CYCOLOY
Protection	IP65 per EN 60529
Safety	EN 61010-1 600 V CAT III, 300 V CAT IV pollution degree 2, double insulation
Type test voltage	5.2 kV ac, 50 Hz / 60 Hz, 5 s

EMC

Emission	IEC/EN 61326-1, EN 55022
Immunity	IEC/EN 61326-1

Power Supply

Functional range	88 to 660 V RMS ac absolute, 50 Hz / 60 Hz
Safety	EN 61010-1 600 V CAT III, 300 V CAT IV, pollution degree 2, double insulation
Fuse	Power supply fuse can be replaced only in service facility. Supply can be connected in parallel to measuring inputs (up to 660 V RMS ac).
Power consumption	5 W
Memory capacity	8 MB Flash-EPROM
Intervals	> 5.600 intervals, > 39 days with 10-min intervals
Events	> 13.000
Memory model	Linear, circular
Interface	RS232, 9600 to 115000 Baud, automatic selection, 3-wire communication.
Dimensions	170 mm x 125 mm x 55 mm
Weight	Approx. 0.9 kg

Measurement

A/D converter	16 bit
Sampling frequency	10.24 kHz
Anti-aliasing filter	FIR-Filter, $f_C = 4.9$ kHz
Frequency response	Uncertainty < 1% of V_m for 40 to 2500 Hz
Interval length	1, 3, 5, 10, or 30 seconds, 1, 5, 10, 15, or 60 minutes
Averaging time for min/max values	$\frac{1}{2}$, 1 line power period 200 ms 1, 3, 5 s
Time base	Resolution: 10 ms (at 50 Hz) deviation: 2 s/day at 23 °C.

Input Voltage

Input range V_1 P-N:	69, 115, 230, or 480 V ac
Input range V_1 P-P	120, 200, 400, or 830 V ac
Max overload voltage	1.2 V_1
Input range selection	By job programming
Connections	P-P or P-N, 1- or 3-phase
Nominal voltage V_N	≤ 999 kV (using PTs and ratios)
Input resistance	Approx. 820 k Ω per channel. Lx-N Single phase (L1 or A, L2 or B, L3 or C connected): app. 300 k Ω
Intrinsic uncertainty	0.1% of V_1
Voltage transformer	Ratio : < 999 kV / V_1
Ratio selection	By job programming

Current Input with Flexi Set

Input ranges I_1 L1 or A, L2 or B, L3 or C, N:	15, 150, 1500, or 3000 A ac
Measuring range	0.75 A to 3000 A ac
Intrinsic uncertainty	$< 2\%$ of I_1
Position influence	Max. $\pm 2\%$ of m.v. for distance conductor to measuring head > 30 mm
Stray field influence	$< \pm 2$ A for $I_{ext} = 500$ A ac and distance to measuring head > 200 mm
Temperature coeff.	0.005% / K
Current transformer	Ratio : ≤ 999 kA / I_1
Ratio selection	By job programming
Connection	3-phase, 3-phase + N 2-phase L1 or A and L3 or C (2 W-meter-method) 7-pole connector

Current Input for Clamp

Input signal:	0.5 V ac nominal (for I_1) 1.4 V peak
Intrinsic uncertainty	< 0.3% of I_1
Max. overload	10 V ac
Input resistance	App. 8.2 k Ω
Current transformer	Ratio : ≤ 999 kA / $\leq I_1$
Ratio selection	By job programming

General Specifications

RMS Logging Slow Voltage Variations

Logging values: Mean value	RMS values averaged over interval length
Min, Max values	Averaging with selectable averaging time from 0.5 periods to 5 s
Max value	Max 10 ms RMS value per interval
Min value:	Min 10 ms RMS value per interval

Current Logging Values

Mean value	RMS values averaged over interval length
Max value	Highest RMS value per interval

Events Dips, Swells, Interruptions

Limit value	Variable Lower limit: 0 to 95% V_N Upper limit: 105 to 120% V_N Set in PQ Log
Range	0 to $V_1 + 20\%$
Logging value	$\frac{1}{2}$ period RMS value
Operating uncertainty	< 2% of V_1
Response time	$\frac{1}{2}$ line power period

Flicker

Logging value	Flicker severity (Pst / Plt) according to IEC 61000-4-15
Intrinsic uncertainty Pst	< 5% of m. v
Measuring range Pst	0.4 to 4

Power (Logging Functions A, P only) P, S, |P|

Active power P	As per EN 61036, class 2
Distorting power D	As per EN 61268, class 2 (A-version only)
Max value	Highest value per interval
Min value	Smallest value per interval
Phase uncertainty	< 0.3 degrees
Conditions	Conductor centered within clamp jaws or Flexi Set

Harmonics

V_m , I_m , THDV, THDI per IEC/EN 61000-4-7, class B

Voltage harmonics (function A) intrinsic uncertainty:	For $V_m < 3\% V_N$: < 0.15% V_N
	For $V_m \geq 3\% V_N$: < 5% V_m
Current harmonics (function A) intrinsic uncertainty	For $I_m < 10\% I_N$: < 0.5% I_N
	For $I_m \geq 10\% I_N$: < 5% I_m
THDV (function A) intrinsic uncertainty at V_N	For THDV < 3%: < 0.15%
	For THDV $\geq 3\%$: < 5%
THDV (function P) intrinsic uncertainty at V_N	For THDV < 3%: < 1%
	For THDV $\geq 3\%$: < 5%
THDI (functions A, P) intrinsic uncertainty at I_1	For THDI < 3%: < 2%
	For THDI $\geq 3\%$: < 5%

Statistics

Frequency	42 classes for 10 s mean values Ripple-control signals
Interharmonics	21 classes for 3 s mean values

Analysis of logging data

Programming and analysis is done by PQ Log software on PC.

Logging Function P

Logging Values

Voltage L1 or A, L2 or B, L3 or C: phase-phase or phase-neutral:

- Voltage (mean, min, and max values)
- THDV (mean, and max values)
- Flicker Pst, Plt
- Voltage events (dips, swells, interruptions)

Current L1 or A, L2 or B, L3 or C, and N:

- Current (mean, max values), THDI

Power:

- Active power P (mean, min, and max values)
- Absolute values active power $|P|$ (mean, min, and max values)
- Apparent power S (mean, min, and max values)
- Power Factor PF, tangent
- Energy per averaging interval

Total Power:

- Total power P, $|P|$, S
- 3-wattmeter and 2-wattmeter method (Aron circuitry)

Application

Power logging:

- Long-term analysis of active, reactive, apparent power
- Long-term analysis of power factor, symmetry

Disturbance analysis:

- Examination of voltage dips and swells, flicker measurement

Network optimization:

- Load measurements, acceptance of new loads
- Efficiency of compensation systems

Logging Function A – “All” parameters

Logging Values

All parameters for voltage quality per EN 50160:

Voltage L1 or A, L2 or B, L3 or C: phase-phase or phase-neutral:

- Voltage (mean, max, min values)
- Voltage harmonics 1st to 50th order
- THDV (harmonic contents of voltage)
- Interharmonics 5 to 2500 Hz (in steps of 0.5 Hz)
- Flicker Pst,Plt
- Unbalance
- Signaling voltages
- Frequency
- Voltage events (dips, swells, interruptions)

Current L1 or A, L2 or B, L3 or C, and N:

- Current (mean, max values)
- Harmonics of phase and neutral currents up to 50th order
- Crest factor and peak values of the currents

Power:

- Active power P (mean, min, and max values)
- Absolute values active power $|P|$ (mean, min, and max values)
- Distorting power D (mean, min, and max values)
- Apparent power S (mean, min, and max values)
- Power Factor PF, tangent
- Energy per averaging interval

Total power:

- Total power P, |P|, D, S
- 3-wattmeter method
- 2-wattmeter method (Aron circuitry)
- 2 ½ wattmeter method

Applications

Power quality:

- Voltage quality analysis according to EN 50160 over a 1-week period (time-activated job)
- Examination of measurement quantities per standards

Disturbance analysis:

- Long-term analysis of line power voltage
- Examination of voltage dips, swells, and harmonic problems
- Flicker measurement
- Examination of ripple control signals (level)
- Specific search for disturbances through correlation of relevant logging quantities (e.g. current, voltage, and flicker), time of occurrence, periodicity

Network Optimization:

- Load logging
- Current logging (with Flexi Set 5 to 3000 A or clamps 1 to 1000 A)
- Capture of current peaks

PQ Log PC Application Software

PQ Log software for Windows® PCs is the application for use with the 1744/1743 Power Quality Logger. The data are also available in ASCII format.

Programs available for setting up the Logger:

- Interval length
- Memory model
- Voltage input range, nominal voltage, nominal current
- Response time for min, max values
- Connection type (P-N, P-P)
- Thresholds for event detection, interruptions

Setup:

- Internal clock (date/time)
- Define 1744/1743 Power Quality Logger designation
- Parameters for data export
- Software updates

Analysis:

- ASCII data export
- Graphical summary of all EN 50160 parameters
- Online test function

Online Test

The following figure shows the online test display.




Figure 18. Online Test

egb024.bmp

ASCII Export

The following figure illustrates the ASCII export display:

	A	B	C	D	E	F	G
39	Date and time	U mean L1	U min L1	U max L1	Flicker Pst L1	Flicker Plt L1	THD U mean L1
40	29.09.98 15:40	232.26	228.40	236.44	0.88	0.88	2.33
41	29.09.98 15:50	231.50	228.02	234.93	0.91	0.89	2.30
42	29.09.98 16:00	232.35	228.90	235.69	0.94	0.91	2.29
43	29.09.98 16:10	233.89	229.91	237.57	0.93	0.92	2.37
44	29.09.98 16:20	233.89	230.41	237.07	0.92	0.92	2.49
45	29.09.98 16:30	233.50	229.78	236.82	0.94	0.92	2.41
46	29.09.98 16:40	234.05	230.16	237.32	0.90	0.92	2.42
47	29.09.98 16:50	234.10	230.92	237.45	0.92	0.92	2.31
48	29.09.98 17:00	234.16	228.78	237.07	0.91	0.92	2.20
49	29.09.98 17:10	234.85	232.05	237.95	0.91	0.92	2.11

egb025.bmp

Figure 19. ASCII Export

For special cases, additional evaluations are available:

- Graphic representation of measured data
- Timeplot diagrams
- Application oriented analysis
- Logging value list
- Table of events (UNIPEDD DISDIP)
- Table summary
- Cumulative frequency, harmonics (logging function A only)
- Statistical values (logging function A only)
- All exceeding table (logging function A only)
- Most critical values (logging function A only)

Timeplot diagram

The following figure shows a typical Timeplot diagram:




Figure 20. Timeplot Diagram

egb026.bmp

UNIPEDE DISDIP Table

The following figure shows a typical UNIPEDE DISDIP table:

Phase L1, L2, L3	< 20 ms	20...< 100 ms	100...< 500 ms	0.5...< 1 s	1...< 3 s	3...< 20 s	20...< 60 s	>= 1 min
Surge >10%								
Dip < 10%								
10...< 15 %						3		
15...< 30 %								
30...< 60 %						3		
60...< 99 %						3		
Interruption								

Recording as events from -10/+10% of the nominal voltage
 Dip according to UNIPEDE measurement guide

Number of surges 0
 Number of Dips 9
 Number of interruptions 0
 Total events and interruptions 9
 Total number of allowed events 100
 Total number of allowed interruptions 100

egb027.bmp

Figure 21. UNIPEDE DISDIP Table

Cumulative Frequency – Harmonics

The following figure shows a typical display of cumulative frequencies for current and voltage harmonics:




Figure 22. Cumulative Frequency – For Voltage and Current Harmonics

—A—

Anti aliasing filter, 28
Apparent Power, 37

—C—

Completing the Logging, 26
Connecting the clip on probes, 14
Connection modes, 27
Connections for Medium Voltage
 Networks, 21
Crest Factor, 37
Current, 37
Current Harmonics, 33

—D—

Disposal, 45

—E—

Energy, 40
Evaluation, 27
Extreme values, 29

—F—

Flicker, 35
Frequency, 36

—I—

Installation at the measuring site, 17
Interharmonics, 11
Interval length, 11
 I_{peak} , 37

—L—

Limit values for events, 11
Lithium Battery, 45

Logging Configurations, 10
Logging input for voltages, 9
Logging segments, 11
Logging with two voltage converters and
 two current transformers, 24

—M—

Maximum nominal voltages, 6, 16
Memory model, 11
Methods of Logging, 27

—N—

Nominal Voltages, 27

—P—

Phase-N, 11
Phase-Phase, 11
Power factor, 37, 39

—R—

Reactive Power, 37

—S—

Sampling rate, 28
signaling voltages, 11
Signaling voltages, interharmonics, 33

—T—

THD I, 35
THD V, 34

—U—

Unbalance, 36
User Interface, 1

—V—

Voltage dips/swells, 32

1744/1743

Users Manual

Voltage Harmonics, 32

Voltage interruptions, 31

Voltage variations, 28

 [Back to the Fluke 1743/1744 Product Page](#)

 [Visit us at www.TestEquipmentDepot.com](http://www.TestEquipmentDepot.com)

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176