



SBS Portable Battery Monitor/Ground Fault Locator

Voltage/Ground Meter/Alarm Relays



50-469-BB

Specifications

Battery Input

90 to 180 VDC, 3VA - For 125V battery

Ground Resistors

30K \pm 1% from each bus to ground

Voltage Indication

0 to \pm 199.9 VDC in 0.6" bright red LED digit and decimal point accuracy is \pm 0.2 VDC

Ranges

- +Bus to Ground (+GND)
- -Bus to Ground (- to GND)
- Ground Fault Voltage (Fault)
- Battery Voltage (BAT)

Scanning

Each range is automatically scanned and read every three seconds.

Alarms

- The "+/- Fault" relay energizes and latches when the + fault voltage exceeds the +/- set value for the time setting. The "alarm" LED lights. Set range is 13.0 to 100.0V
- "Hi Battery" and "Low Battery" relays energize and latch when the battery voltage exceeds the "Hi" or "Low" set value for the time setting. ("Hi" set range is 125.0 to 150.0V, and the "Low" set range is 100.0 to 125.0V)

Time Delay

Can be set from 5 to 60 seconds

Reset

Panel push button or remote contact closure will reset an alarm provided the cause is removed

Contact Rating

2A at 120 VAC or 28 VDC

Limit Setting

Limits and time delay are set by removing the front bezel (4 screws). This can safely be done with power on.

Available Output Options

- 0 to 1mADC (isolated) into 0 to 10K load for 90 to 180 VDC input. Accuracy is \pm 0.1% of FS. P/N is 50-469-I01-BB
- 4 to 20 mADC (isolated) into 0 to 500 OHM load for 90 to 180 VDC input. Accuracy is \pm 0.1% of FS. P/N is 50-469-I420-BB
- Digital: RS232/485 with DNP3.0 or Modbus, P/N is 50-469-J3.0-BB

*Additional voltages

P/N: 50-471-BB=48V Battery

P/N: 50-472-BB=250V Battery

Other voltages available - consult factory

Fault Indicator Specifications

- Operation — Hand-activated on-off button/switch
- Features — Automatic selection of grounded line. Does not interfere with sensitive electronic equipment, radio, etc.
- Receiver — Does not contact circuitry; LED and sound indicators
- Sensitivity — Up to 100 Ω resistance